



9000 Series

9000 SERIES PART NUMBER KEY

Throttle - 9**X**XXX

0 = None

1 = Standard Mechanical Throttle

2 = Standard Electronic Throttle

5 = Premium Mechanical Throttle

6 = Premium Electronic Throttle

Gear - 9**X**XXX

0 = None

1 = Mechanical Gear

2 = Solenoid Gear

3 = Mechanical Gear / Solenoid 2 Speed

4 = Solenoid Gear / Solenoid 2 Speed

Troll - 9**X**X**X**

0 = None

1 = Mechanical Troll

2 = Solenoid Troll

3 = Autotroll

5 = Mechanical Governed Troll

6 = Solenoid Governed Troll

Number of Stations - 9**X**XXX**X**

0 = All control stations and power / start interlock require hardwiring.

1 -5 = The number of control stations prewired with pigtail cable and plugs and power / start interlock.

			Part Numbering / Identification Guide											
			Part Number											
			90010	91000	91102	91202	91212	91222	92000	92102	92112	92212	95232	96232
Engine/Throttle	None	0	X											
	Mechanical	1		X	X	X	X	X						
	Electrical	2							X	X	X	X		
	Premium Mechanical	5											X	
	Premium Electronic	6												X
Gear/Clutch	None	0	X	X					X					
	Mechanical	1			X					X	X			
	Solenoid	2				X	X	X				X	X	X
	Mechanical Gear / Solenoid 2	3												
	Solenoid Gear / Solenoid 2 Speed	4												
Troll	None	0		X	X	X			X	X				
	Mechanical	1	X				X				X	X		
	Solenoid	2						X						
	Autotroll	3											X	X
	Mechanical Governed Troll	5												
	Solenoid Governed Troll	6												